



①

Integrated board (Heat&Cool)



②

Touch controller



③

Power filter plate



④

Reactor (big)



⑤

Electronic expansion valve



⑥

4-way valve



⑦

Water flow switch



⑧

Fan motor



⑨

Full set of sensors



⑩

Compressor



⑪

Titanium heat exchanger (Heat&Cool)



⑫

Evaporator



⑬

High pressure protection switch



⑭

Low pressure protection switch



⑮

Low pressure valve




⑯

Liquid reservoir




⑰

Water union



⑱

Water union gasket




⑲

Fan



⑳

Drainage kit



AXCR21

Position	Spare parts	Code
1	Integrated board (Heat&Cool)	033093551000A48
2	Touch controller	034092390101
3	Power filter plate	033092340000
4	Reactor (big)	041301100000
5	Electronic expansion valve	006121010001
6	4-way valve	006110210001
7	Water flow switch	040060620000
8	Fan motor	032051580000
9	Full set of sensors	Z35043000400
10	Compressor	031064060000
11	Titanium heat exchanger (Heat&Cool)	001031220003
12	Evaporator	Z01010650000
13	High pressure protection switch	040050630000
14	Low pressure protection switch	040050130000
15	Low Pressure valve	006080500000
16	Liquid reservoir	/
17	Water union (Black, 50mm)	003990020000
18	Water union gasket	004980050003
19	Fan	007010070000
20	Drainage kit	Z03991700000
21	Top cover	002021722615
22	Front Panel	0020217227P1
23	Right Up Panel	002021722915
24	Right Down Panel	0020217230P1
25	Back Panel	0020217231P1
26	Bottom board	002021735400
27	Left mesh board	0020217228P1